FIT1047 Tutorial 8 – Sample Solution

Topics and goals

- Network layers and protocols, learn about addresses at various layers
- Application layer HTTP
- Familiarise yourself with some of the networking tools

Instructions

The tasks are supposed to be done in groups of two or three students.

Task 0: Basic knowledge

Briefly explain the following terms:

1. Bit rate, bandwidth

Bit rate: the numbers of bits that can be transmitted over a data communications channel per time unit, usually measured in bits per second (or kilobits, megabits, gigabits per second). Bandwidth: strictly speaking, the width of a range of frequencies (i.e. highest minus lowest frequency). E.g. each channel in WiFi has a bandwidth of 20 MHz. But it's often used as a synonym for bit rate.

2. Latency

The time it takes for a message from being sent to being received. Note that a network can have a very high bit rate but still feel slow: e.g. consider using a satellite connection for a video conference: you can stream very high quality video over the satellite connection, but due to the high latency, you could experience a delay of several seconds, which makes the connection almost unusable for real-time communication. This is also often a problem when playing real-time online video games.

3. Networks layers, PDU, encapsulation




Figure 1: The PuTTY telnet client

Task 1: "Browsing" the web

In this exercise, you will directly "talk" to a web server, without using a web browser. We will use a **telnet** program, which can establish a connection to a server and then send and receive textual data over that connection.

Figure 1 shows a screen shot of the PuTTY telnet client, which is installed on the Monash lab computers. The screenshot shows you how to set it up for this exercise: check the host name, port, connection type and "close window on exit".

When you click "Open", a black window will appear in which you can enter commands that are sent to the web server at www.csse.monash.edu. Your task is to request a particular page, which is at /~guidot/ on that server.

Note: If you are using Mac OS or Linux on your own machine, open a terminal window and type telnet www.csse.monash.edu 80 instead.

1. The most basic form of request (defined in an older version of HTTP) looks like this:

GET /~guidot/

Try entering this request and have a look at the result.

2. The version of HTTP currently in use is 1.1. A request in this version must be composed of a GET line (ending in HTTP/1.1 to specify the newer protocol version), followed by a Host: line that identifies the host that the request is sent to (in this case it should be www.csse.monash.edu), followed by an empty line. Try out this type of request as well. What difference do you notice?

There are two main differences: (1) the response contains additional headers that deliver some metadata about the requested web page; (2) the connection is not closed immediately, but remains open for a few seconds, which enables the browser (or us) to make another request without first opening a new connection. This behaviour was introduced in order to make HTTP requests more efficient for modern web pages, which often need to request hundreds of files ("assets", such as JavaScript, CSS and images) in order to display a single page.

Task 2: Packet sniffing

A packet analyser (sometimes also called "packet sniffer") is a program that can log all packets that are received and transmitted over a network interface. We will be using Wireshark, a very popular open-source tool for packet analysis. You can download it on your own computer from www.wireshark.org, or use the version installed on the Monash lab computers.




Figure 2: The network where the traffic was captured

This week, we will analyse a sequence of packets captured on Guido's network at home. You can download the log file that Wireshark produced from the FIT1047 Moodle site (week 7). The file is called Wireshark_http_example.pcap. The diagram in Figure 2 explains how Guido's computer is connected to the Monash web server.

- 1. Start Wireshark and load the capture file (see Fig. 3). After opening the file, the main window should look like the one in Fig. 4.
- 2. Select "frame" number 6 (as in Fig. 4). This frame shows a request sent from Guido's home computer to the web server at www.csse.monash.edu, requesting his homepage
- 3. Familiarise yourself with the three main sections (panes) of the Wireshark window:
 - The packet list pane displays a summary of each packet captured. When you click on a packet here, the other two panes are updated with the details for that packet.
 - The packet details pane below shows information about the selected packet.
 - The packet bytes pane displays the raw data for the selected packet. It highlights the data for the field that is selected in the packet details pane.




Figure 3: Wireshark File menu

Navigate between the panes and explore the relationships between the displayed pieces of information.

- 4. Click on frame 6.
 - a) How long is it in bytes?

432 bytes

b) Which application layer protocol does it use?

HTTP

- 5. There are five lines in the packet details pane for frame 6, each of which can be expanded by clicking on the "+" symbol.
 - a) Can you identify what they stand for?

From top to bottom: the entire frame captured by Wireshark; the data link layer; the network layer; the transport layer; the application layer.

b) Which protocols are being used?

From top to bottom: Ethernet; IP version 4; TCP; HTTP.




Figure 4: Wireshark main window

- c) What are the names of the PDUs for each protocol?
 - Ethernet: frame; IP: packet; TCP: segment; HTTP: message.
- d) Recall that each protocol layer encapsulates the message from the layer above and adds a header. What are the sizes of the headers for each PDU used in frame 6?

You can find the size by clicking on the relevant protocol line and counting the number of bytes highlighted in the bottom pane. Some protocols also tell you the size when you open the details view. Ethernet: 14 bytes; IP: 20 bytes; 32 bytes; HTTP: we can consider the entire contents to be the actual message, there are no additional headers (such as the ones for TCP or IP).